

WARNING DO NOT DISASSEMBLE THIS MARKER WHILE IT IS PRESSURIZED WITH AIR. DO NOT PRESSURIZE A PARTIALLY ASSEMBLED MARKER. www.usarmypaintball.com TA06208 Tippmann Service Department Shroud 1-800-533-4831 Complete TA05052 www.tippmann.com (right half) Feed Latch Bolt (2) PL-42D Hopper Nut Feed 98-45 Flat Washer Elbow Latch -PL-42C Hopper Bolt 98-04 Feed Elbow Feed Elbow Pin (2) 98-26 Valve Lock Bolt (2) Feed Lock Spring TA05021 98-14 Power Feed Lock Tube 9-PA 98-15 Nut Feed Lock Pin-TA06040 FA-18 Receiver Ball Latch-(Right) TA05004 Split Grip TA02021 (Right). Link Arm Pin (2) CA-02A CA-14-TA06006 Drive Spring Grip End 98-33 CA-36 \Screw Cap CA-15 Guide Pin Receiver Sear Dowel 98-57 Buffer O-Ring Pin (4) (Black) 98-09N 98-091 Gas Line 98-20 Trigger / Return Slide Spring PL-01A Nut Adapter Bolt (Yellow)(2). (short) CA-08B TA06017 Sear End Cap Adapter 98-06A Cover Nut (2) 98-37N Safety Adapter Bolt (long) M TO TA02036 98-06 INTERNAL Sear Tank VALVE PARTS: Spring Adapter Valve Disassembly Safety 98-18 O-Ring (Red) Not Recommendéd Trigger Return TA06044 98-25N Valve Body-Trigger SL2-25 Valve Seat O-Ring (2) 98-19 Slide PA-31A Valve Snap Ring Return Slide FA-07 98-56 Valve Plug Dowel Pin (2) Safety 98-32 Valve Spring O-Ring (Black) 98-PL Valve Plunger CA-27 Front Valve Seat REV 05/22/2009